



The **DVS** Series Voice Evacuation Control Panel (VECP) provides a full selection of power and performance, with features that can be selected to fit any Voice Evacuation or Mass Notification applications.

<u>Feature</u>	Power Out Watts	Number of Speakers (*1)	Number of Speaker Circuits	Zone Selectable	Output Meters	Number of Messages	Power Supply (Included)	Battery Size for 24h/15m
Model								
DVS-25	25	34	4	No	Power/Level	2	Ext-1.5A (*2)	+2.4Ah
DVS-25P	25	34	4	No	Power/Level	2	Internal	2x 7Ah-Int
DVS-50	50	67	4	No	Power/Level	2	Ext-2.8A (*2)	+2.7Ah
DVS-50P	50	67	4	No	Power/Level	2	Internal	2x 7Ah-Int
DVS+50	50	67	1 ~ 2	No	Level	7	Internal	2x 12Ah-Int
DVS+50/4	50	67	4	Yes	Level	7	Internal	2x 12Ah-Int
DVS+50/8	50	67	8	Yes	Level	7	Internal	2x 12Ah-Int
DVS+50/12	50	67	12	Yes	Level	7	Internal	2x 12Ah-Int
DVS+50/16	50	67	16	Yes	Level	7	Internal	2x 12Ah-Int
DVS+50/20	50	67	20	Yes	Level	7	Internal	2x 12Ah-Int
DVS+100	100	135	2 ~ 4	No	Level	7	Internal	2x 12Ah-Int
DVS+100/4	100	135	4 ~ 6	Yes-4	Level	7	Internal	2x 12Ah-Int
DVS+100/8	100	135	8	Yes	Level	7	Internal	2x 12Ah-Int
DVS+100/12	100	135	12	Yes	Level	7	Internal	2x 12Ah-Int
DVS+100/16	100	135	16	Yes	Level	7	Internal	2x 12Ah-Int
DVS+100/20	100	135	20	Yes	Level	7	Internal	2x 12Ah-Int
DVS+150	150	200	3 ~ 6	No	Level	7	Ext-10A	2x 12Ah-Int
DVS+150/4	150	200	4 ~ 8	Yes-4	Level	7	Ext-10A	2x 12Ah-Int
DVS+150/8	150	200	8 ~ 10	Yes-8	Level	7	Ext-10A	2x 12Ah-Int
DVS+150/12	150	200	12	Yes	Level	7	Ext-10A	2x 12Ah-Int
DVS+150/16	150	200	16	Yes	Level	7	Ext-10A	2x 12Ah-Int
DVS+150/20	150	200	20	Yes	Level	7	Ext-10A	2x 12Ah-Int
DVS+200	200	267	4 ~ 8	No	Level	7	Ext-12A	4x 7Ah-Int
DVS+200/4	200	267	4 ~ 10	Yes-4	Level	7	Ext-12A	4x 7Ah-Int
DVS+200/8	200	267	8 ~ 12	Yes-8	Level	7	Ext-12A	4x 7Ah-Int
DVS+200/12	200	267	12 ~ 14	Yes-12	Level	7	Ext-12A	4x 7Ah-Int
DVS+200/16	200	267	16	Yes	Level	7	Ext-12A	4x 7Ah-Int
DVS+200/20	200	267	20	Yes	Level	7	Ext-12A	4x 7Ah-Int

*1) approximate number, assuming an average of 3/4-Watts per speaker

*2) DVS-25/50 External power not included, must be supplied from listed source.

Add Ah number to Supply's battery calc.